


Category	Blind No.	Name
Generic	1	Not in Service
	2	PSW Advert (used for event stands, etc..)
	3	PSW Logo
	4	Bus on Road Test
	5	Awaiting Recovery
	6	Driver on Rest Break
	7	Special Service
	8	Private Hire
	9	Shuttle Bus
	10	Dial a Ride
	11	School Service
	12	UK Coach Rally
	13	Derby
	14	Nottingham
	15	Loughborough
	16	Leicester
Holidays/ Excursions/ Shuttles	17	Another Great Day Out....
	18	Another Great Holiday....
	19	DOWNLOAD RIP Shuttle
	20	DOWNLOAD Hotel Shuttle
	21	University of Nottingham Open Day
	22	Loughborough University Open Day
Rail Replacements	23	East Midlands Rail Replacement
	24	Cross Country Rail Replacement
	25	LNER Rail Replacement
	26	Rail Replacement (all other operators)
School Services	27	X27 – Mountsorrel then Rothley
	28	S68 Castle Donington College
	29	S70 Castle Donington College
	30	S306 Rawlins Academy
	31	S325 Iveshead Academy
	32	S327 Iveshead Academy
	33	482 Costock Primary School
	34	483 East Leake Academy
	35	485 East Leake Academy
	36	485 Sutton Bonington Primary School
	37	S704 East Leake Academy
Loughborough Schools Foundation	38	F Loughborough Schools Foundation
	39	I Loughborough Schools Foundation
	40	K Loughborough Schools Foundation
	41	O Loughborough Schools Foundation
	42	Q Loughborough Schools Foundation
	43	LSF – Quorn Sports Ground
	44	LSF – Loughborough Leisure Centre
	45	LSF – Loughborough University Sports
	46	LSF – Soar Valley Leisure Centre

## To Set Destination Blind



Press the green tick button **once**. The first digit of the destination number will begin to flash.

Use the up/down arrows to set the first digit.

Press the right arrow **once**. The second digit of the destination number will begin to flash.

Use the up/down arrows to set the second digit.

**Wait a few seconds and you will see on screen –**

“Please wait, sending destinations.”

**The destination blind should now be set.**